

PC-Woody® Epoxy

PC-Woody® is an epoxy paste formulated to replace missing and rotten wood with structural strength greater than most wood.

PC-Woody® is a non-solvent, shape and form, non-shrink, non-crack, flexible paste epoxy. It delivers a natural wood color for interior or exterior use.

Use for permanent repairs on exterior or interior projects. Unlike typical wood fillers, PC-Woody® is a permanent wood repair product.

Mixing Instructions:

Using separate knives, mix equal parts of can A with can B onto a flat surface until a uniformed tan color is present. Mixing for a longer period of time will reassure better performance.

Mixing Tips:

In cold or cool temperatures, warm product containers with a gentle heat source. PC-Woody® mixes easily and spreads like peanut butter. The warmer the application temperature the easier it is to spread. A small putty knife is an excellent tool for both mixing and applying. For best results, allow 15-20 minutes of standing time after mixing before shaping and molding.

Application Instructions:

Apply PC-Woody® to a dry, clean surface removing all dry rot, dirt, saw dust or loose coating materials.

Product Working Time: At 70°F PC-Woody® will remain workable for ½ an hour and will cure overnight.

Product Cure Time: Full cure achieved in one week. It will take longer in colder temperatures.

After Product Cures: PC-Woody® can be stained, painted, drilled, machined, sanded, filed or sawn.



DISTRIBUTED BY MOUNTAIN HOME BUILDING PRODUCTS

www.mountainhomebuildingproducts.com

sales@mountainhomebuildingproducts.com

Toll Free 800.490.3695